

2C



Rear Shock Absorber Adjustment

Spring Pre-load Adjustment

- Fully turn the adjuster (1) counterclockwise. From that position (softest), turn it counterclockwise to standard setting position.

Rear shock absorber spring pre-load

Standard: 11th clicks clockwise from soft position



Damping Force Adjustment

NOTE:

- Turn the adjuster clockwise to stiffen the damping force and turn it counterclockwise to soften the damping force.
- Fine-tune the adjusters by turning it slightly until punch marks align.

Fully turn the rebound damping force adjuster (1) clockwise. From full hard position, turn it out to standard setting position.

Rear shock absorber rebound damping force

1.25 turns counterclockwise from full hard position

