





4. Apply grease to the showing points.
Install the Spacers (B) and (C) to the center stand pivots.

 99000-25010:
SUZUKI SUPER GREASE
"A" or equivalent



5. Install the Center Stand (A) with the Bolts (H) (LH) and (M) (RH). Tighten each bolts to the specified torque.

 Bolt


(G)(L):

23 N·m (2.3 kgf-m, 16.5 lbf-ft)

(H)(M):


50 N·m (5.0 kgf-m, 36.0 lbf-ft)

6. Install the Cushion (I) to the Plate (L) (E).



7. Apply grease to the spring hooking points.
Install the Springs (J) and (K) using the special tool.

NOTE: Check for smooth movement of the center stand.

 99000-25010:
SUZUKI SUPER GREASE
"A" or equivalent

 09920-20310: Spring hook

