

1G



Fuel Feed Hose Removal and Installation

Removal

- 1) Remove the air cleaner box.
- 2) Disconnect the fuel feed hose (1).



Installation

Install the fuel feed hose in the reverse of removal.