


1G



Fuel Hose Inspection

- 1) Lift and support the fuel tank.
- 2) Inspect the fuel feed hose (1) for damage and fuel leakage. If any defects are found, the fuel feed hose (1) must be replaced.
- 3) Any leakage from the connecting section (2), replace the fuel feed hose (1) with a new one.



- 4) After finishing the fuel feed hose inspection, install the removed parts.