

1K



Exhaust System Inspection

Inspect the exhaust pipe connection and muffler connection for exhaust gas leakage and mounting condition. If any defect is found, replace the exhaust pipe assembly or muffler with a new one. Check the exhaust pipe bolts, muffler connecting bolt, exhaust pipe connecting bolts and muffler support bolt are tightened to their specified torque.

Tightening torque

Exhaust pipe bolt (a): 23 N·m (2.3 kgf-m, 17.0 lbf-ft)

Muffler connecting bolt (b): 18 N·m (1.8 kgf-m, 13.0 lbf-ft)

Muffler support bolt (c): 30 N·m (3.0 kgf-m, 22.0 lbf-ft)

Exhaust pipe connecting bolt (d): 18 N·m (1.8 kgf-m, 13.0 lbf-ft)



