

























































0C


















## Special Tools

  <p><b>09900-06107</b> Snap ring pliers (Open type)</p>	  <p><b>09900-06108</b> Snap ring pliers (Close type)</p>	  <p><b>09900-18740</b> Hexagon socket (24 mm)</p>	  <p><b>09900-20101</b> Vernier calipers (150 mm)</p>	  <p><b>09900-20102</b> Vernier calipers (200 mm)</p>
  <p><b>09900-20202</b> Micrometer (25 - 50 mm)</p>	  <p><b>09900-20204</b> Micrometer (75 - 100 mm)</p>	  <p><b>09900-20530</b> Cylinder gauge set</p>	  <p><b>09900-20602</b> Dial gauge</p>	  <p><b>09900-20607</b> Dial gauge</p>
  <p><b>09900-20701</b> Dial gauge chuck</p>	  <p><b>09900-20803</b> Thickness gauge</p>	  <p><b>09900-20805</b> Tire depth gauge</p>	  <p><b>09900-20806</b> Thickness gauge</p>	  <p><b>09900-21304</b> V blocks</p>
  <p><b>09900-22301</b> Plastigage (0.025 - 0.076 mm)</p>	  <p><b>09900-22302</b> Plastigage (0.051 - 0.152 mm)</p>	  <p><b>09900-22403</b> Small bore gauge (18 - 35 mm)</p>	  <p><b>09900-25008</b> Multi circuit tester set</p>	  <p><b>09900-25009</b> Needle-point probe set</p>
  <p><b>09900-28630</b> TP Sensor test lead</p>	  <p><b>09904-41010</b> SUZUKI Diagnostic system set</p>	  <p><b>09910-60611</b> Universal clamp wrench</p>	  <p><b>09912-66310</b> Micrometer (0 - 25 mm)</p>	  <p><b>09913-50121</b> Oil seal remover</p>

  <p><b>09913-60230</b> Journal bearing remover &amp; installer</p>	  <p><b>09913-60241</b> Journal bearing holder</p>	  <p><b>09913-70210</b> Bearing installing set (10 - 75 Φ)</p>	  <p><b>09915-40620</b> Oil filter wrench</p>	  <p><b>09915-63311</b> Compression gauge attachment</p>
  <p><b>09915-64512</b> Compression gauge</p>	  <p><b>09915-74521</b> Adapter hose</p>	  <p><b>09915-74533</b> Oil pressure gauge adapter</p>	  <p><b>09915-77331</b> Oil pressure gauge (1000 kPa)</p>	  <p><b>09916-10911</b> Valve lapper set</p>
  <p><b>09916-14510</b> Valve lifter</p>	  <p><b>09916-14522</b> Valve lifter attachment</p>	  <p><b>09916-34542</b> Reamer handle</p>	  <p><b>09916-34550</b> Valve guide reamer (5.5 mm)</p>	  <p><b>09916-34580</b> Valve guide reamer (10.8 mm)</p>
  <p><b>09916-44910</b> Valve guide installer &amp; remover</p>	  <p><b>09916-53340</b> Valve guide installer attachment</p>	  <p><b>09916-84511</b> Tweezer</p>	  <p><b>09917-47011</b> Vacuum pump gauge set</p>	  <p><b>09918-78211</b> Radiator cap tester kit</p>
  <p><b>09918-78220</b> Radiator cap tester adapter</p>	  <p><b>09919-28620</b> Sleeve protector</p>	  <p><b>09920-13120</b> Crankshaft remover</p>	  <p><b>09920-31020</b> Extension handle</p>	  <p><b>09920-53740</b> Clutch sleeve hub holder</p>

  <p><b>09921-20240</b> Bearing remover set</p>	  <p><b>09922-22711</b> Drive chain cutting and joint tool set</p>	  <p><b>09924-74570</b> Final drive gear bearing installer</p>	  <p><b>09924-84510</b> Bearing installer set</p>	  <p><b>09924-84521</b> Bearing installer set</p>
  <p><b>09925-18011</b> Bearing installer</p>	  <p><b>09930-10190</b> Spark plug socket</p>	  <p><b>09930-11920</b> Torx® bit (JT40H)</p>	  <p><b>09930-11940</b> Torx® bit holder (3/8 sq.)</p>	  <p><b>09930-11950</b> Torx® wrench (T25H)</p>
  <p><b>09930-30450</b> Rotor remover bolt</p>	  <p><b>09930-40113</b> Flywheel rotor holder</p>	  <p><b>09930-44530</b> Rotor holder</p>	  <p><b>09930-44541</b> Rotor holder</p>	  <p><b>09930-73110</b> Starter torque limiter holder</p>
  <p><b>09930-73120</b> Starter torque limiter socket</p>	  <p><b>09930-82720</b> Mode select switch</p>	  <p><b>09930-82760</b> Mode select switch</p>	  <p><b>09940-14911</b> Steering stem nut socket wrench</p>	  <p><b>09940-14940</b> Swingarm pivot thrust adjuster wrench</p>
  <p><b>09940-14960</b> Steering stem nut socket wrench</p>	  <p><b>09940-14980</b> Engine mounting adjust wrench</p>	  <p><b>09940-14990</b> Engine mounting adjust wrench</p>	  <p><b>09940-30221</b> Front fork cylinder holder</p>	  <p><b>09940-40211</b> Fuel pressure gauge adapter</p>

 <b>09940-40220</b> Fuel pressure gauge attachment	 <b>09940-52841</b> Front fork inner rod holder	 <b>09940-52861</b> Front fork oil seal installer set	 <b>09940-54860</b> Front fork cylinder holder attachment	 <b>09940-63110</b> Torx® bit (E8)
 <b>09940-92720</b> Spring scale	 <b>09940-93110</b> Fork spring compressor	 <b>09940-94922</b> Front fork spring stopper plate	 <b>09940-94930</b> Front fork spacer holder	 <b>09941-34513</b> Bearing installer
 <b>09941-54911</b> Bearing outer race remover	 <b>09943-74111</b> Front fork oil level gauge	 <b>09943-88211</b> Pinion bearing installer	 <b>09944-28321</b> Hexagon socket (19 mm)	 <b>99565-01010-034</b> CD-ROM Ver.34

Torx® is the registered trademark of Camcar Division of Textron inc. U.S.A.