

1A



## DTC P1650 (C42)

### DTC Detecting Condition and Trouble Area

DTC detecting condition	Trouble area
<b>P1650 (C42): IG Switch Circuit Malfunction</b> Ignition switch signal is not input to the ECM. When the ID agreement is not verified. ECM does not receive communication signal from the immobilizer antenna. (If equipped)	<ul style="list-style-type: none"><li>• Ignition switch</li><li>• ECM</li><li>• Immobilizer system</li><li>• Immobilizer system circuit</li></ul>

### Troubleshooting

Refer to [Ignition Switch Inspection](#) for details.