


**1B**

## PCV Hose Removal and Installation

Refer to [Intake System Components](#).

### Removal

- 1) Remove the air cleaner box. 
- 2) Remove the PCV hose.

### Installation

- 1) Install the PCV hose.
- 2) Install the removed parts.