

1C



## Tightening Torque Specifications

Fastening part	Tightening torque			Note
	N·m	kgf-m	lbf-ft	
Intake pipe clamp screw	1.5	0.15	1.0	
Throttle cable lock-nut	4.5	0.45	3.5	
STP sensor mounting screw	3.5	0.35	2.5	
TP sensor mounting screw	3.5	0.35	2.5	
Fuel delivery pipe mounting screw	3.5	0.35	2.5	
EVAP system purge control solenoid valve bracket screw	5	0.5	4.0	
EVAP system purge control solenoid valve nut	7	0.7	5.0	
IAT sensor screw	1.3	0.13	1.0	
ECT sensor	18	1.8	13.0	
HO2 sensor	25	2.5	18.0	
EXCV cable guide bolt	10	1.0	7.5	
Rear brake master cylinder mounting bolt	10	1.0	7.5	

### Reference:

For the tightening torques of fasteners not specified in this page, refer to:

[Throttle Cable Routing Diagram](#)

[Throttle Body Assembly Components](#)

[Fasteners Information](#)