


1D



Cam Chain Tension Adjuster Inspection

Refer to [Cam Chain Tension Adjuster / Cam Chain Tensioner / Cylinder Head Assembly / Cam Chain Guide / Cylinder Removal](#) and [Cam Chain Tension Adjuster / Cam Chain Tensioner / Cylinder Head Assembly / Cam Chain Guide / Cylinder Installation](#).

Unlock the ratchet (1), and move the push rod (2) in place to see if it slides smoothly. If any stickiness is noted or ratchet mechanism is faulty, replace the cam chain tension adjuster assembly with a new one.



[A]:	Front cylinder cam chain tension adjuster
[B]:	Rear cylinder cam chain tension adjuster