

1D

## Cam Drive Idle Gear / Sprocket No. 2 Bushing Inspection



Refer to [Cam Chain Tension Adjuster / Cam Chain Tensioner / Cylinder Head Assembly / Cam Chain Guide / Cylinder Removal](#) and [Cam Chain Tension Adjuster / Cam Chain Tensioner / Cylinder Head Assembly / Cam Chain Guide / Cylinder Installation](#).

Inspect the cam drive idle gear/sprocket No. 2 bushing (1) for wear or damage. If any defects are found, replace the cam drive idle gear/sprocket No. 2 with a new one.

