

1G



## Fuel Mesh Filter Inspection

Refer to [Fuel Pump Disassembly and Reassembly](#).

- Inspect the fuel mesh filter is clogged with foreign particles. If the fuel mesh filter is dirtied excessively, replace the fuel mesh filter with a new one.

