


1H



## Ignition System Diagram



[A]:	For Thailand, Canada, California (U.S.A) and China	5.	ECM	11.	Side-stand relay
[B]:	Except for Thailand, Canada, California (U.S.A) and China	6.	Ignition coil #1 (Center)	12.	Ignition fuse
1.	CKP sensor	7.	Ignition coil #1 (Side)	13.	Ignition switch
2.	TP sensor	8.	Ignition coil #2 (Center)	14.	Main fuse
3.	ECT sensor	9.	Ignition coil #2 (Side)	15.	Battery
4.	GP switch	10.	Engine stop switch		