


Starting System Diagram

1I



1.	Starter motor	4.	Engine stop switch	7.	Ignition switch	10.	Ignition fuse
2.	Starter relay	5.	Starter button	8.	Side-stand switch	11.	Main fuse
3.	Clutch lever position switch	6.	Side-stand relay	9.	Gear position switch	12.	Battery