



Tightening Torque Specifications

Fastening part	Tightening torque			Note
	N·m	kgf-m	lbf-ft	
Starter motor mounting bolt	10	1.0	7.5	
Starter motor lead wire mounting nut	6	0.6	4.5	
Starter clutch bolt	25	2.5	18.0	

Reference:

For the tightening torques of fasteners not specified in this page, refer to:

[Starter Motor Components](#)

[Fasteners Information](#)