


1J



Battery Visual Inspection

- 1) Remove the seat. 
- 2) Visually inspect the surface of the battery container.
If any signs of cracking or electrolyte leakage from the sides of the battery have occurred, replace the battery with a new one.
If the battery terminals are found to be coated with rust or an acidic white powdery substance, clean the battery terminals with sandpaper.
- 3) Install the seat.