

2C



## Rear Shock Absorber Inspection

Refer to [Rear Shock Absorber Removal and Installation](#).

### Shock Absorber

Inspect the rear shock absorber for damage and oil leakage, and absorber bushing for wear and damage. If any defect is found, replace the rear shock absorber with a new one.

**NOTICE:**

**Do not attempt to disassemble the rear shock absorber. It is unserviceable.**



### Spacer

Inspect the spacer for any flaws or other damage. If any defect is found, replace the spacer with a new one.



### Rear Shock Absorber Bearing

- 1) Insert the spacer into bearing.
- 2) Check the play by moving the spacer up and down. If excessive play is noted, replace the bearing with a new one.

