

2D




Rear Wheel Damper Removal and Installation

Refer to [Rear Sprocket Mounting Drum Assembly Removal and Installation](#).

Removal

- 1) Remove the rear wheel dampers (1).



Installation

Reference: [Rear Wheel Damper Inspection](#)

Install the rear wheel dampers in the reverse order of removal. Pay attention to the following points:

- Install the rear wheel dampers (1).

NOTE:

Three protrusions (2) on the wheel damper must face outside.

