

4B



## Front Brake Caliper Parts Inspection

Refer to [Front Brake Caliper Disassembly and Reassembly](#).

### Brake Caliper Cylinder

Inspect the brake caliper cylinder wall for nicks, scratches or other damage. If any damage is found, replace the caliper with a new one.



### Brake Caliper Piston

Inspect the brake caliper pistons surface for any scratches or other damage. If any damage is found, replace them with new ones.



### Brake Pad Mounting Pin

Inspect the brake pad mounting pins for wear and other damage. If any damage is found, replace them with new ones.



## Brake Pad Spring

Inspect the brake pad spring for damage and excessive bend. If any defects are found, replace it with a new one.

