


# 4E-7 ABS:

## ABS Control Unit / HU Diagram

BENE31J14502002



IE31J1450007-02

[A]: Rear brake solenoid OUT	3. Pump motor	9. ABS indicator light
[B]: Rear brake solenoid IN	4. ABS motor fuse (25 A)	10. SDS coupler
[C]: Front brake solenoid OUT	5. ABS valve fuse (15 A)	11. Mode select coupler
[D]: Front brake solenoid IN	6. Battery	12. Front wheel speed sensor
1. Valve relay	7. Ignition fuse (10 A)	13. Rear wheel speed sensor
2. Motor relay	8. Ignition switch	