



Visual Inspection

Check the following parts and systems visually.

Inspection Item		Referring Section
Connectors of electric wire harness	Disconnection, friction	Precautions for Electrical Circuit Service
Fuses	Burning	Precautions for Electrical Circuit Service
Brake pad	Worn	Front Brake Pad Inspection and Rear Brake Pad Inspection
Brake fluid	Level, leakage	Brake Fluid Level Check
ABS indicator light	Operation	ABS Indicator Light Inspection
Tire	Pressure	Tire Inspection and Cleaning
	Type, size	Tire Inspection and Cleaning
	Damage, wear	Tire Inspection and Cleaning
Wheel	Runout, play	Wheel / Wheel Axle Inspection
Other parts that can be checked visually		—

NOTICE:

- The standard tire fitted on this motorcycle is 110/80R19M/C 59V for front and 150/70R17M/C 69V for rear. The use of tires other than those specified may cause instability. It is highly recommended to use a SUZUKI Genuine Tire.
- Replace the tire as a set, otherwise the DTC C1625 (25) may be stored.