

5C




## Clutch Master Cylinder Parts Inspection

Refer to [Clutch Master Cylinder / Clutch Lever Disassembly and Reassembly](#).

### Master Cylinder

Inspect the master cylinder bore (1) for any scratches or other damage. If any damage is found, replace the master cylinder with a new one.



### Piston

Inspect the piston surface for any scratches or other damage. If any damage is found, replace it with a new one.

### Rubber Parts

Inspect the primary cup (1), secondary cup (2) and dust boot (3) for wear or damage. If any damage is found, replace them with new ones.

