

5C



Clutch Push Rod (Left) Inspection

Refer to [Clutch Release Cylinder / Clutch Push Rod \(Left\) Removal and Installation](#).

Inspect the clutch push rod (left) for wear or bend. If any defects are found, replace it with a new one.

