







9B



Headlight Symptom Diagnosis

Condition	Possible Cause	Action
Low beam does not light up	Circuit fuse blown.	Replace fuse and check short circuit.
	Bulb blown.	Replace bulb. 
	Wiring or ground faulty.	Repair wiring. 
	Dimmer switch faulty.	Check dimmer switch. 
High beam does not light up	Circuit fuse blown.	Replace fuse and check short circuit.
	Bulb blown.	Replace bulb. 
	Wiring or ground faulty.	Repair wiring. 
	Dimmer switch faulty.	Check dimmer switch. 
	Passing switch faulty.	Check passing switch. 