

9B




## Turn Signal Light Bulb Replacement

[Reference: Front Turn Signal Light / Rear Turn Signal Light Components](#)


**NOTE:**

The same procedures is applicable to both the right and left lights.

- 1) Remove the screw (1) and lens (2).



- 2) Replace the bulb (1) with a new one.



- 3) After finishing the front turn signal light bulb replacement, reinstall the front turn signal light.