


Repair Instructions

Combination Meter Construction

BENE31J19306020



IE31J1930026-01

[A]: Install the coupler boots to the combination meter firmly.	2. Meter panel	[b] : 4.5 N·m (0.45 kgf·m, 3.5 lbf·ft)
1. Combination meter	[a] : 1.5 N·m (0.15 kgf·m, 1.0 lbf·ft)	